
TP-Link HX510 Set Up Guide - Wired

To set up TP-Link HX510 as a regular router, follow the steps below to connect your mesh device.


Note: If your house or office already has ethernet cables /ethernet ports, we recommend connecting the Mesh device via this wired connection.




Connect the Hardware


- 1. Connect the power adapter to the mesh device.
- 2. Connect the WAN/LAN port of the mesh device to your modem/router's ethernet port via an ethernet cable. This node (Mesh Unit) will automatically synchronise with the Main Modem/Router.
- 3. Verify the status LED is flashing blue before continuing with the configuration.

- 4. Connect your computer to the mesh device:
 - Method 1: Wired: Turn off Wi-Fi on your computer and connect it to the LAN port of the mesh device using an Ethernet cable.



- Method 2: Wireless
 - Locate the SSID (Network Name) and Wireless Password printed on the label at the bottom of the mesh device.
 - Click the network icon on your computer or go to the Wi-Fi
 Settings on your smart device, then select the SSID to join the
 network.





Smart Device

Online URL:

https://articles.spintel.net.au/article/tp-link-hx510-set-up-guide-wired.html