
## **TP-Link HX510 Set Up Guide - Wired**

To set up TP-Link HX510 as a regular router, follow the steps below to connect your mesh device.


**Note**: If your house or office already has ethernet cables /ethernet ports, we recommend connecting the Mesh device via this wired connection.




## **Connect the Hardware**


- 1. Connect the power adapter to the mesh device.
- 2. Connect the WAN/LAN port of the mesh device to your modem/router's ethernet port via an ethernet cable. This node (Mesh Unit) will automatically synchronise with the Main Modem/Router.
- 3. Verify the status LED is flashing blue before continuing with the configuration.


- 4. Connect your computer to the mesh device:
  - Method 1: Wired: Turn off Wi-Fi on your computer and connect it to the LAN port of the mesh device using an Ethernet cable.



- Method 2: Wireless
  - Locate the SSID (Network Name) and Wireless Password printed on the label at the bottom of the mesh device.
  - Click the network icon on your computer or go to the Wi-Fi
    Settings on your smart device, then select the SSID to join the
    network.







Online URL:

https://articles.spintel.net.au/article/tp-link-hx510-set-up-guide-wired.html