

Home Wireless Broadband Troubleshooting Steps

Before you proceed, please check on our [network status page](#) for any outage reported in your area.

Note: For new customers, you need to activate the SIM card online first by visiting our [activation page](#) before you can use the service.

Choose the issue below to take you directly to the steps:

- [Can't connect to the internet](#)
- [Getting a Slow Connection](#)
- [Review Modem Settings](#)
- [Resetting your Modem](#)

Can't connect to the internet

1. Confirm Modem Status lights are stable.



MODE indicator	Cyan/blue: Connected to an LTE/3G network.
Signal indicators	Green: signal reception available (more indicators mean better reception).

2. If the Internet light/LTE is off, power cycle the modem. Unplug the modem for at least 3 minutes from the power source and plug it back in.

3. Once all the lights are back ON, review the modem settings.

Note: If you want to improve LTE signal strength, always make sure that the modem is near to a window and the antennas are installed. Avoid putting the modem near to microwaves, refrigerator or oven since it will affect modem radio signal performance of your devices and its connection to the tower.

4. If everything has been checked and the issue persists, reset your modem with caution. If the issue won't fix on the first attempt, contact us for further assistance to avoid damaging the modem.



[Back to Top](#)

Getting a slow connection

The Full Speed 4G service is a best of service and speeds are determined by many factors all in which are determined by the network carrier in order to keep the network in the best condition for all users.

The speeds on the 4G Internet Unlimited plan are limited to a maximum download speed of 20Mbps and a maximum upload speed of 2Mbps.

However, if the speed is unbearably slow, check out the steps below.

1. **Confirm all devices are affected** via wired and/or WiFi.
Observe the connection in the morning, afternoon or evening as it might be a network congestion affecting your speed.
2. Review Modem Settings
As for the **AC800S** modem (being mobile), try other areas other than your home location as the issue may be location specific. If you are using **Huawei B818**, see this [article](#).
3. **Make sure the modem is getting signal bars.**
Consider placing your Wireless Modem as close as possible to a window, with few obstructions. Depending on your location, you may receive a stronger signal in certain parts of your home.
4. **If the issue persists, unplug the modem from the power source for at least 3 minutes and plug it back in.** As soon as all the lights will turn on, run a [speed test](#) if there's any difference.
5. Reset your modem. If everything has been checked, and there's no improvement with the speed, reset your modem with caution. If the issue won't fix on the first attempt, [contact us](#) for further assistance to avoid damaging the modem.



[Back to Top](#)

Modem Settings

- [Netcomm NL1901](#)
- [Huawei B525](#)
- [Netgear AC800S](#)
- [Huawei B818](#)
- [Huawei B628](#)

Netcomm NL1901

- Access the modem gateway and change the **Net Select** mode from Auto to LTE.

If your area is on a 2300Mhz high indoor coverage, you can use LTE Band 40 to maximise the available high speed.

NL1901ACV

Device Info

Basic Setup

Advanced Setup

Layer 2 Interface

WAN Service

Mobile Broadband

LAN

NAT

Security

Parental Control

Quality of Service

Routing

DSL

UPnP

DNS Proxy

DLNA

Storage Service

Interface Grouping

IP Tunnel

IPSec

Multicast

Wireless

Voice

Diagnostics

Management

Logout

<input checked="" type="checkbox"/>	Support NDIS
<input checked="" type="checkbox"/>	DHCP
<input checked="" type="checkbox"/>	Enable NAT
User Name:	<input type="text"/>
Password:	<input type="text"/>
Authentication Method:	AUTO <input type="button" value="v"/>
APN:	OWHWBB <input type="text"/>
Dial Number:	*99# <input type="text"/>
Net Select:	LTE <input type="button" value="v"/>
Dial Delay(in sec.):	10 <input type="text"/>
Default WAN Connection Select:	Mobile Broadband <input type="button" value="v"/>

Apply/Save

[Back to Top](#)

Huawei B525

- In a web browser, enter the URL <http://192.168.8.1/html>

- Go to **Settings** then **Network Settings**



Current connection


Upload/Download: 554.88 KB / 3.55 MB
Duration: 01:09:54

WiFi status


WiFi status: On
Current users: 0

Previous login information

IP address: 192.168.8.102
Time: 2018-11-7 9:48:54
Status: Normal




- Make sure that the **Preferred Mode** under **Network** is set to **4G with 2300** (if 2300 MHz is available in your area) or **4G Only** (if it's within 1800 Mhz/700 MHz) and click **Apply** and **OK**



Huawei B628

- In a web browser enter the URL <http://192.168.8.1/html>
- Go to **Network Settings > Mobile Network Searching**



Make sure that the **Preferred Mode** under **Network** is set to **4G with 2300** (if address shows high indoor, no NQR/Outage for 2300 Mhz) or **4G Only** (if address shows high indoor, no NQR/Outage 1800 Mhz/700 Mhz) and click **Apply** and **OK**.

[Back to Top](#)

Resetting your Modem

This will remove any changes you have made to the settings on your modem, including Wi-Fi password changes. To re-apply them, see this [article](#). Here are the steps in resetting the modem:

1. Using a paper clip or a toothpick, push the small pinhole found at the back of the modem. Push this for **15** seconds (or until all the LEDs turn off) then release.

2. Allow up to five minutes for system reset and automatic reboot.
3. Access the gateway and reconfigure your modem with the preferred settings before you run a test.

[Back to Top](#)

Online URL:

<https://articles.spintel.net.au/article/home-wireless-broadband-troubleshooting-steps.html>