


How to Set Up Port Forwarding for Netcomm modem

Note: You need to know the IP address of the device you want to forward the ports to and follow the steps below. For BYO modem, please refer to your manufacturer's manual.


1. To access modem interface, please make sure your device is connected to the modem (wired or wirelessly)

Enter **192.168.20.1** into the browser address bar, type **admin** in the username and password field then click OK




2. Once logged in, go to Advanced Setup

3. Select NAT and click on Add



4. Choose **Custom Service** and enter your desired name.

Tick **Enable LAN Loopback** and enter the IP address of the device to which the external port numbers are to be forwarded on the **Server IP Address** field.



5. Make sure **Status** is Enabled

Click on **External Port Start** and enter the first port number of the required

Click Apply/Save

Online URL:

<https://articles.spintel.net.au/article/how-to-set-up-port-forwarding-for-netcomm-modem.html>