How to Update Netcomm Modem's Firmware Version

Important Note: Updating firmware without fair knowledge on how it works might damage the modem, for safety, you may call Netcomm support or proceed at your own risk.

1. Login to modem <u>Graphic User Interface</u>. Type **admin** in the username and password field, then click on the **Login** button.

?	A username and password are being requested by http://192.168.20.1. The site says: "Broadband Router"
User Name:	admin
Password:	admin

Note: If the default administrator login does not work, you might have changed the login credentials before or you may try to factory-reset the modem.

2. Go to **Management > Update Firmware** and follow the steps.

You may also click here.

NetCommWireless		
NF10WV Device Info Basic Setup Advanced Setup Wireless Voice Diagnostics Management Settings System Log Security Log SNMP Agent TR-069 Client Internet Time Access Control Update Firmware Reboot Logout	Tools Update Software Step 1: Obtain an updated software image file from your ISP. Step 2: Enter the path to the image file location in the box below or click the 'Browse' button to locate the image file. Step 3: Click the 'Update Software' button once to upload the new image file. NOTE: The update process takes about 2 minutes to complete, and your Broadband Router will reboot. Software File Name: Choose File No file chosen Update Software	

For further assistance, you may contact <u>Netcomm Support</u> and advise them that you want to use the modem with a different firmware version.

Online URL: <u>https://articles.spintel.net.au/article/how-to-update-netcomm-modem-s-firmware-version.html</u>