Configuring your Netgear Modem

To get connected via your Netgear modem, you'll need to log into your modem gateway.

Note: This can be done on most mobile devices, but we recommend doing these steps with your PC if you have one.


Logging into your modem

To access modem gateway enter http://www.routerlogin.com in the address bar of a web browser. If it does not work or if it has been changed, check your router's IP address. For instructions, click here.


Use **admin** for username field and **password** in the password field then click on **Login**.

For Older Version

1. Once logged in, click **Setup Wizard**



2. Select "No. I Want To Configure By Myself." > Next Otherwise, go to **Basic Settings** and it will lead you to the same page where you can complete the setup



3. Choose "Yes" and enter the username and password provided to you via email

- 4. "Get Dynamically From ISP" for both Internet IP Address and Domain Name Server (DNS) Address
- 5. "Apply" to save the changes

Wait 3-5 minutes for the modem to go online, then test the service. Reboot modem if needed.

Through NETGEAR Genie

1. Once logged in, select **Internet**. The following screen displays:



2. Select Yes on *Does your Internet connection require a login?* and enter the username and password provided to you via email. Click **Apply** to save the new settings.

Note: If other settings are presented, accept default values

Wait **3-5 minutes** for the modem to go online, then test the service. Reboot modem if needed.

Setting up your Home Phone

If your order includes a Home Phone service, it's time to get it up and running. This detailed <u>guide</u> will walk you through every step needed to set up your home phone using your own modem.

Online URL:

https://articles.spintel.net.au/article/configuring-your-netgear-modem.html