

WiFi connection does not work With SpinTel Supplied Modem - NBN

Symptom

- Devices are able to connect to the WiFi network but unable to access any website.

Things to check first

- Confirm if able to connect using a wired connection.
- Confirm all devices are unable to connect to the Wifi network.
- If you are using the default SSID or WiFi name, check the base of your modem and make sure you are connected to the correct WiFi Name

Troubleshooting

1. Access modem gateway and check if the WiFi Name/SSID is the right one you are currently connected.

NF10WV

Device Info
Advanced Setup
Wireless
Basic
Security
MAC Filter
Wireless Bridge
Advanced
Station Info
Voice
Diagnostics
Management
Logout

Wireless -- Security

This page allows you to configure security features of the wireless LAN interface.
You may setup configuration manually
OR
through WiFi Protected Setup(WPS)
Note: When both STA PIN and Authorized MAC are empty, PBC is used. If Hide Access Point enabled or Mac filter list is e

WPS Setup

Enable WPS

Add Client (This feature is available only when WPA-PSK, WPA2 PSK or OPEN mode is configured)
 Push-Button Enter STA PIN Use AP PIN

Set WPS AP Mode

Setup AP (Configure all security settings with an external registrar)

Device PIN [Help](#)

Manual Setup AP

You can set the network authentication method, selecting data encryption, specify whether a network key is required to authenticate to this wireless network and specify the encryption strength. Click 'Apply/Save' when done.

Select SSID: [WiFi Name](#)

Network Authentication:

Protected Management Frames:

WPA/WAPI passphrase: [Click here to display](#) [Click to display WiFi password](#)

WPA Group Rekey Interval:

WPA/WAPI Encryption:

WEP Encryption:

If you are connected to the correct WiFi name, try changing wireless credentials on the modem gateway or recreate WiFi connection by forgetting and inputting the password on the device.

Do the following below if you are not connected to the correct WiFi name.

- WiFi name/SSID is visible on the device
- WiFi name/SSID is not hidden in the modem's gateway unless you will

need to manually enter the username and password.

NF10WV

Device Info
Advanced Setup
Wireless
Basic
Security
MAC Filter
Wireless Bridge
Advanced
Station Info
Voice
Diagnostics
Management
Logout

Wireless -- Basic

This page allows you to configure basic features of the wireless LAN interface. You can enable or disable the wireless LAN requirements.
Click 'Apply/Save' to configure the basic wireless options.

Enable Wireless
 Hide Access Point
 Clients Isolation
 Disable WMM Advertise
 Enable Wireless Multicast Forwarding (WMF)

SSID:

BSSID:

Country:

Max Clients:

Wireless - Guest/Virtual Access Points:

Enabled	SSID	Hidden	Isolate Clients	Enable WMM Advertise	Enable WMF	Enable HSPOT	Max Clients	BSSID
<input type="checkbox"/>	<input type="text" value="w/0_Guest1"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="text" value="16"/>	N/A	
<input type="checkbox"/>	<input type="text" value="w/0_Guest2"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="text" value="16"/>	N/A	
<input type="checkbox"/>	<input type="text" value="w/0_Guest3"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="text" value="16"/>	N/A	

2. Factory Reset modem.

3. If all the troubleshooting will not work, please feel free to contact us and a friendly Customer Care will assist you.

Online URL:

<https://articles.spintel.net.au/article/wifi-connection-does-not-work-with-spintel-supplied-modem-nbn.html>